

VIPERLOK®

INSTALLATION

For use with Copper, CPVC, and PEX pipe.
Designed for use with water or air at 200 psi non-shock.*

Installation:

1. Cut pipe square and remove all burrs. In order to make a reliable seal the tube must be free of scratches and imperfections.
2. Do not remove plastic insert bushing.
3. Push pipe fully into fitting and then rotate to check connection and adjust handle position.
4. Test for leaks.
5. Restrain and support pipe on both sides of fitting to prevent movement and stress on the connection.
Do not hang anything on the pipe.

Removal:

Viper-Lok fittings can be removed by pressing the plastic removal tool against the plastic end-piece to release the pipe.

* VIPER-LOK connections are not suitable for PEX-AL-PEX or PEX tubing with an oxygen barrier.



www.americanvalve.com

1.800.645.0101

Meets California Prop. 65
61 < 5
Drinking Water Standards

Printed in China